



Output fuse and cable diameter should be done to fit with the size of the load.

Chasis ground cable should be the same diameter as the thickest cable in the installation.

Dept. R&D	Technical reference Installatio Guide	Created by JKW	Approved by MBN
CLAYTON POWER		Document type Application Diagram	Document status Released
		Title Installation Guide LPS II Supercharge Setup	
Rev. 3.00	Date of issue 12/06/2025	Sheet 1/1	